

South Atlantic

ACG Bahia Blanca, ARG	L2N	P	0230	0630	1030	1430	1830	2230
		D	Spanish on 490 kHz!					
			0030	0430	0830	1230	1630	2030
ACG Buenos Aires, ARG	L2G	R	0250	0650	1050	1450	1850	2250
		F	Spanish on 490 kHz!					
			0050	0450	0850	1250	1650	2050
ACG Comodoro Rivadavia, ARG	L3B	O	0220	0620	1020	1420	1820	2220
		C	Spanish on 490 kHz!					
			0020	0420	0820	1220	1620	2020
ACG Mar del Plata, ARG	L2T	Q	0240	0640	1040	1440	1840	2240
		E	Spanish on 490 kHz!					
			0040	0440	0840	1240	1640	2040
ACG Rio Gallegos, ARG	L3I	N	0210	0610	1010	1410	1810	2210
		B	Spanish on 490 kHz!					
			0010	0410	0810	1210	1610	2010
ACG Ushuaia, ARG	L3O	M	0200	0600	1000	1400	1800	2200
		A	Spanish on 490 kHz!					
			0000	0400	0800	1200	1600	2000
Cape Town R, SAF	ZSC	C	0020	0420	0820	1220	1620	2020
La Paloma R, URG		F	English					
			0050	0450	0850	1250	1650	2050
		A	Spanish on 490 kHz!					
			0000	0400	0800	1200	1600	2000
Mindelo R, Sao Vicente, CPV	D4A	U	0320	0720	1120	1520	1920	2320
		P	Portuguese on 490 kHz!					
			0230	0630	1030	1430	1830	2230
Port Elizabeth R, SAF	ZSQ	I	0120	0520	0920	1320	1720	2120
Walvis Bay R, NMB	V5W	B	0010	0410	0810	1210	1610	2010

West Pacific / Sea of Japan

Amboina R, INS	PKE	B	0010	0410	0810	1210	1610	2010
Byunsan R, KOR		W	English					
			0340	0740	1140	1540	1940	2340
		K	Korean on 490 kHz!					
			0140	0540	0940	1340	1740	2140
Chukpy R, KOR		V	English					
			0330	0730	1130	1530	1930	2330
		J	Korean on 490 kHz!					
			0130	0530	0930	1330	1730	2130
Jayapura R, INS	PNK	A	0000	0400	0800	1200	1600	2000
Kholmsk R, FE, RUS	UFO	B	0010	0410	0810	1210	1610	2010
Kushiro R, JAP	JNX	K	0140	0540	0940	1340	1740	2140
		K	Japanese on 424 kHz!					
			0108	0508	0908	1308	1708	2108
Magadan R, FE, RUS	UIB	D	0030	0430	0830	1230	1630	2030
Miri R, Sarawak, MLA		T	0310	0710	1110	1510	1910	2310